

1 Before driving

1-1. Hybrid system

Hybrid system.....	28
Hybrid system precautions.....	31
Energy monitor/ consumption screen	36
Hybrid vehicle driving tips.....	41

1-2. Key information

Keys	43
------------	----

1-3. Opening, closing and locking the doors

Smart access system with push-button start	48
Wireless remote control.....	59
Side doors	63
Back door	66

1-4. Adjustable components (seats, mirrors, steering wheel)

Front seats.....	77
Rear seats.....	82
Driving position memory	86
Head restraints.....	89
Seat belts	91
Steering wheel.....	99
Anti-glare inside rear view mirror.....	101
Outside rear view mirrors.....	102

1-5. Opening and closing the windows and moon roof

Power windows.....	105
Moon roof	108

1-6. Refueling

Opening the fuel tank cap.....	112
--------------------------------	-----

1-7. Theft deterrent system

Immobilizer system	117
Alarm.....	119
Theft prevention labels (for U.S.A.).....	121

1-8. Safety information

Correct driving posture	122
SRS airbags	124
Front passenger occupant classification system.....	136
Child restraint systems	141
Installing child restraints.....	145

2 When driving

2-1. Driving procedures

Driving the vehicle	158
Power (ignition) switch	168
Hybrid transmission	173
Turn signal lever	181
Parking brake	182
Horn.....	183

2-2. Instrument cluster

Gauges and meters	184
Indicators and warning lights.....	187
Multi-information display	191
Head-up display	197

2-3. Operating the lights and windshield wipers

Headlight switch.....	202
Automatic High Beam	207
Fog light switch	213
Windshield wipers and washer.....	215
Rear window wiper and washer.....	220
Headlight cleaner switch	221

2-4. Using other driving systems

Cruise control	222
Dynamic radar cruise control.....	226
Intuitive parking assist	237
Electronically modulated air suspension	244
Rear view monitor system (rear view mirror-attached type).....	250
Driving assist systems.....	254
Hill-start assist control	260
Pre-Collision System.....	262

2-5. Driving information

Utility vehicle precautions	266
Cargo and luggage	271
Vehicle load limits.....	275
Winter driving tips	276
Trailer towing (AWD models with towing package).....	280
Trailer towing (2WD models and AWD models without towing package).....	293
Dinghy towing	294

3 Interior features

3-1. Using the air conditioning system and defogger

Automatic air conditioning system	298
Rear window defogger switch.....	305
Windshield wiper de-icer	306

3-2. Using the audio system

Audio system	307
Using the radio.....	311
Using the CD player.....	321
Playing MP3 and WMA discs.....	331
Operating an iPod® player.....	341
Operating a USB memory player.....	349
Optimal use of the audio system	358
Using the AUX adapter	361
Using the steering wheel audio switches	363

3-3. Using the Bluetooth® audio system

Bluetooth® audio system	366
Using the Bluetooth® audio system.....	369
Operating a Bluetooth® enabled portable player	374
Setting up a Bluetooth® enabled portable player	378
Bluetooth® audio system setup	385

3-4. Using the hands-free phone system (for mobile phones)

Hands-free system for mobile phones.....	386
Using the hands-free system (for mobile phones).....	390
Making a phone call.....	398
Setting a mobile phone.....	403
Security and system setup.....	409
Using the phone book.....	413

3-5. Using the interior lights

Interior lights list.....	420
• Interior lights	421
• Personal lights	421

3-6. Using the storage features

List of storage features.....	423
• Glove box	424
• Bottle holders/ door pockets	425
• Cup holders.....	426
• Console box.....	428
• Auxiliary boxes.....	430
• Under tray	431

3-7. Other interior features

Sun visors.....	432
Vanity mirrors.....	433
Clock.....	434
Outside temperature display (vehicles without a navigation system)	435
Multi-display light control (vehicles without a navigation system)	436
Power outlets	437
Seat heaters and ventilators	440
Armrest	442
Coat hooks	443
Floor mat.....	444
Luggage compartment features.....	445
Garage door opener.....	449
Compass.....	455
Safety Connect	459

4 Maintenance and care

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior.....	468
Cleaning and protecting the vehicle interior	471

4-2. Maintenance

Maintenance requirements	474
General maintenance.....	476
Emission inspection and maintenance (I/M) programs	480

4-3. Do-it-yourself maintenance

Do-it-yourself service precautions	481
Hood	484
Positioning a floor jack.....	485
Engine compartment.....	487
12-volt battery.....	499
Tires	506
Tire inflation pressure.....	515
Wheels	520
Air conditioning filter.....	522
Electronic key battery	525
Checking and replacing fuses	527
Headlight aim	543
Light bulbs.....	546

5 When trouble arises

5-1. Essential information

Emergency flashers.....	566
If your vehicle needs to be towed	567
If you think something is wrong	573
Event data recorder	574

5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds... ..	576
If a warning message is displayed.....	585
If you have a flat tire.....	606
If the hybrid system will not start.....	620
If the shift lever cannot be shifted from P.....	622
If you lose your keys	623
If the electronic key does not operate properly	624
If the vehicle 12-volt battery is discharged	627
If your vehicle overheats	630
If the vehicle becomes stuck.....	635

6 Vehicle specifications

6-1. Specifications

Maintenance data (fuel, oil level, etc.).....	638
Fuel information.....	650
Tire information.....	653

6-2. Customization

Customizable features.....	666
----------------------------	-----

6-3. Initialization

Items to initialize	675
---------------------------	-----

7 For owners

Reporting safety defects for U.S. owners.....	678
Seat belt instructions for Canadian owners (in French).....	679

Index

Abbreviation list 684

Alphabetical index..... 686

What to do if... 698

1

2

3

4

5

6

7